



RADION universal transmitter RFUN

Bosch Security Systems, Inc.
130 Perinton Parkway
Fairport, NY 14450
USA
www.boschsecurity.com

1 | Before you begin



NOTICE!

Resistors must be wired as shown in this document for correct operation. Complete all wiring and make sure external contacts are sealed and the transmitter cover is closed before learning in the device.

2 | Setting the jumper




Figure 1.1: Module overview

Callout – Description
1 – Jumper on. Use external input or normal contact.
2 – Jumper off. Use external input only.

2 | Wiring to an external contact

Applicable to ICP-CC488, sol 16+, 16i, 64, *144/6000




Figure 2.1: Wiring diagram

* The solution 144/6000 can use the external contact as well as its normal contact by learning it in as channel 1 and channel 2.

Applicable to CC488




Figure 2.2: Wiring diagram

Copyright

This document is the intellectual property of Bosch Security Systems, Inc. and is protected by copyright. All rights reserved.

Trademarks

All hardware and software product names used in this document are likely to be registered trademarks and must be treated accordingly.

Bosch Security Systems, Inc. product manufacturing dates

Use the serial number located on the product label and refer to the Bosch Security Systems, Inc web site at: <http://www.boschsecurity.com/datecodes/>.

